


Australian R/C Radio Bands and Frequencies



The list of frequencies below shows the authorized channels that can be used by Australian radio control model boating clubs. They are the **only narrowband** frequencies approved for the operation of model sail and power boats in Australia ([AMPBA](#)). Channel restrictions are not required by the new 2.4GHz spread-spectrum radio equipment also used for model boating.

Please respect fellow club members and limit your sailing to 20 minutes at a time if others share the same frequency as you, unless they are happy for you to continue.

27 MHz SURFACE FREQUENCIES – BOAT / CAR

| Channel | Frequency | Channel | Frequency |
|---------|-----------|---------|-----------|
| 1 | 26.975 | 7 | 27.125 |
| 2 | 26.995 | 8 | 27.145 |
| 3 | 27.025 | 9 | 27.175 |
| 4 | 27.045 | 10 | 27.195 |
| 5 | 27.075 | 11 | 27.225 |
| 6 | 27.095 | 12 | 27.255 |

29 MHz SURFACE FREQUENCIES – BOAT / CAR

| Channel | Frequency | Channel | Frequency |
|---------|-----------|---------|-----------|
| 10 | 29.725 | 24 | 29.865 |
| 12 | 29.745 | 26 | 29.885 |
| 14 | 29.765 | 28 | 29.905 |
| 16 | 29.785 | 30 | 29.925 |
| 18 | 29.805 | 32 | 29.945 |
| 20 | 29.825 | 34 | 29.965 |
| 22 | 29.845 | 36 | 29.985 |

36 MHz BOATING FREQUENCIES (Odd Channels)

| Channel | Frequency | Channel | Frequency | Channel | Frequency |
|---------|-----------|---------|-----------|---------|-----------|
| 601 | 36.010 | 621 | 36.210 | 641 | 36.410 |
| 603 | 36.030 | 623 | 36.230 | 643 | 36.430 |
| 605 | 36.050 | 625 | 36.250 | 645 | 36.450 |
| 607 | 36.070 | 627 | 36.270 | 647 | 36.470 |
| 609 | 36.090 | 629 | 36.290 | 649 | 36.490 |
| 611 | 36.110 | 631 | 36.310 | 651 | 36.510 |
| 613 | 36.130 | 633 | 36.330 | 653 | 35.530 |
| 615 | 36.150 | 635 | 36.350 | 655 | 36.550 |
| 617 | 36.170 | 637 | 36.370 | 657 | 36.570 |
| 619 | 36.190 | 639 | 36.390 | 659 | 36.590 |

36 MHz BOATING INTERMEDIATE FREQUENCY INTERFERENCE

| Channel #1 | Channel #2 | Channel #1 | Channel #2 |
|------------|------------|------------|------------|
| 601 | 647 | 609 | 655 |
| 603 | 649 | 611 | 657 |
| 605 | 651 | 613 | 659 |
| 607 | 653 | | |

40 MHz GENERAL R/C MODEL FREQUENCIES (Incl. Boats)

| Channel | Frequency | Channel | Frequency | Channel | Frequency |
|---------|-----------|---------|-----------|---------|-----------|
| 67 | 40.670 | 77 | 40.770 | 88 | 40.925 |
| 69 | 40.690 | 79 | 40.790 | 90 | 40.965 |
| 71 | 40.710 | 81 | 40.810 | 92 | 40.985 |
| 73 | 40.730 | 83 | 40.830 | | |
| 75 | 40.750 | 85 | 40.850 | | |